Certiq on Boomer M1L

All available information for the specified machine types



Operation

Utilization
Utilization hours (machine off/idle/working)
Utilization %
Engine hours
Drill hours
Drill cycle
Pump hours
Location
Site position

Administration (admins only)

/ tarimistration (aarimis only)	
User settings	
Machine cottings	

Organization settings

Available alarms

Engine oil pressure low critical	
Engine coolant temp high critical	
Hydraulic oil temp high critical	
Hydraulic oil level low critical	
Transmission oil temperature high critical	
The second section of the second form softing t	

(Some variations of supported alarms may exist due to model year and engine alternative)

Maintenance

Diagnostic
Active alarms
No. of alarms
Alarm type trending (engine/hydraulics/others)
Alarm frequency (Count and time for each type)
Acknowledge alarm
Connectivity
Last communication
Service
No. of machines in overdue status
No. of reported services
Predicted date for next service
Hours to next service
Reports
Excel reports

Report subscription

Notification	
Mail notification	
SMS notification	

SE-701 91 Örebro, Sweden Phone no: +46 (0)10 7550 000 Org no: 556077-9018

