
Certiq on DM45, DM50, DM2





Operation

Utilization

Engine hours*

Drill hours*

Dril cycle

Fuel consumption

Total liters

Liter per hour

Total CO₂ emission

Location

GPS onboard (position Long/Lat)

Maintenance

Service

No. of machines in overdue status

No. of reported services

Predicted date for next service

Hours to next service

Diagnostic

Active alarms

No. of alarms*

Alarm type trending (engine/hydraulics/others)

Alarm frequency (count and time for each type)

Acknowledge alarm

Connectivity

Last communication

Reports

Excel reports
Report subscription
Notification
Mail notification
SMS notification

Engineering (admins only)

Events
Event overview
Event history
Trend (not available yet)
Trend detail
Trend developer
Log
Register log
Event log

Administration (admins only)

User settings

Machine settings

Infrastructure
Organization settings
Machine communication
Available alarms
Available alarms Engine air filter clogged warning
Engine air filter clogged warning
Engine air filter clogged warning Water in fuel warning

(Some variations of supported alarms may exist due to model year and engine alternative)

Compressor air filter clogged warning

^{*}Available in selected markets on all factory delivered machines

SE-701 91 Örebro, Sweden Phone no: +46 (0)10 7550 000 Org no: 556077-9018

