

Certiq on Scooptram ST7, ST7LP, ST14, ST18







^{*}Available with Certiq onboard functionality

Diagnostic

Active alarms

No. of alarms

Alarm type trending (engine/hydraulics/others)

Alarm frequency (Count and time for each type)

Acknowledge alarm

Connectivity

Last communication

Reports


Excel reports

Report subscription

Notification

Mail notification

SMS notification



- [
- 1	1	C	U			u	п	
Ì	¥	Latest machine data:	12-10-2015 12:00:00 AM					
	ΙТ	Machine model	Machines	Date	Accumulated total ton	Number of Buckets	Average tonnes per bu	E
	IJ	ST18	ST18 UL27	2015-11-04	536 061,4	156	8,26	
	IJ	ST18	ST18 UL27	2015-11-05	536 144,0	7	11,45	
	П	ST18	ST18 UL27	2015-11-06	536 144,0	0	0,00	
	ΙТ	ST18	ST18 UL27	2015-11-07	537 240,3	99	11,06	Г
	IJ	ST18	ST18 UL27	2015-11-08	538 440,5	115	10,42	Ī
	lΙ	ST18	ST18 UL27	2015-11-09	539 573,3	99	11,49	Ξ
	Ш	ST18	ST18 UL27	2015-11-10	540 742,0	77	15,23	
	lΙ	ST18	ST18 UL27	2015-11-11	542 456,5	166	10,33	Ĺ
	IJ	ST18	ST18 UL27	2015-11-12	0,0	52	7,39	Ī

(Some variations of supported alarms may exist due to model year and engine alternative)

Administration (admins only)

User settings

Machine settings

Organization settings

Available alarms

Engine oil pressure low critical

Engine oil level low warning

Engine intake air filter clogged critical

Engine intake air temperature high critical

Engine oil temperature high

Engine overspeed warning

Engine overspeed

Engine coolant temp high critical

Engine coolant level low critical

Hydraulic oil temp high critical

Hydraulic oil level low warning

Hydraulic oil level low critical

Hydraulic oil filter clogged warning

Hydraulic oil filter clogged critical

Transmission oil temperature high critical

Transmission oil pressure low critical

Transmission oil level low warning

Transmission failure warning

Transmission filter blocked warning

Upbox oil filter blocked warning

Upbox oil temperature high warning

Upbox lubrication oil flow low warning

Lubrication failure warning

Lubrication level low warning

Brake fluid temperature high critical

Brake fluid filter clogged warning

Brake fluid level low warning

Brake accumulator pressure low critical

Brake accumulator pressure low warning

Brake temperature high

Brake pressure high

Brake test needed warning

Brake test fail warning

DPF level 2 warning
DPF level 3 critical

DEF level 3 critical

Battery voltage low warning

SE-701 91 Örebro, Sweden Phone no: +46 (0)10 7550 000 Org no: 556077-9018