
Certiq on Boomer M2 D, L1 D, L2 D





Operation

Utilization

Utilization hours (machine off/idle/working)

Utilization %

Engine hours

Drill hours

Drill cycle

Pump hours

Location

Site position

Administration (admins only)

User settings

Machine settings

Infrastructure

Organization settings

Machine communication

Maintenance

Diagnostic

Active alarms

No. of alarms

Alarm type trending (engine/hydraulics/others)

Alarm frequency (Count and time for each type)

Acknowledge alarm

Connectivity

Last communication

Service

No. of machines in overdue status

No. of reported services

Predicted date for next service

Hours to next service

Reports

Excel reports

Report subscription

Notification

Mail notification

SMS notification

Available alarms

Engine oil pressure low warning
Engine coolant temp high warning
Hydraulic oil temp high critical
Hydraulic oil level low warning
Transmission oil temp high alarm
Transmission oil pressure low

(Some variations of supported alarms may exist due to model year and engine alternative)

SE-701 91 Örebro, Sweden Phone no: +46 (0)10 7550 000 Org no: 556077-9018

